

F19, 2

= Defector (multi-sensor) X = Annunciator Display

F16 3-1

= Defector (multi-sensor) = Annunciator Display

F16 3-3

= Detector (multi-sensor) X = Annunciator Display

F16 3-2

= Detector (multi-sensor) X = Annunciator Display

F16 4-1

= Detector (multi-sensor) R1 X = Annunciator Display F16 4-2

= Detector (multi-sensor) X = Annunciator Display

F165-1

= Detector (multi-sensor) = Annunciator Display F16 5-2